



SHIELD AMR
for the RMSW

Exploded Diagram / Kit List



Remove slide plate as per manufactures instructions.

1 - Fit the brass plugs into the large holes in the RMSw.

2 - Place the SHIELD AMR hood on top of the RMSw and make sure the holes are aligned with the holes and brass plugs of the RMSw

3 - Screw in the screws to each of the holes until a tight fit is achieved and there is no movement.

IMPORTANT!!
PLEASE ENSURE ALL FIREARMS ARE CLEAR AND
SAFE BEFORE CONTINUING



Scan the QR code for video showing how the SHIELD ARM fits to the RMSw



ENSURE THAT YOU KEEP TOOLS SAFE FOR FUTURE USE